21 GALLON 2.5 HP AIR COMPRESSOR

START UP GUIDE

ITEM 67847

1 Connect AIR LINE to Coupler.



2 Close DRAIN VALVE at bottom of tank.





3 Fill COMPRESSOR PUMP to proper level with AIR COMPRESSOR OIL.

(Oil sold separately)



4 Plug cord into grounded 120 Volt outlet and turn POWER SWITCH on.

5 If COMPRESSOR does not start, press RESET BUTTON.



CENTRALPNEUMATIC®

Typical Air Line Setup



Thread seal tape is recommended for all threaded connections.

Recommended Accessories

- 3/8" Air Hose
- 1/4" Accessory Kit
- Inline Air Filter

Use of an extension cord is not recommended.

COMPRESOR DE AIRE DE 21 GALONES Y 2.5 HP

GUÍA DE INICIO

ARTÍCULO 67847

1

Conecte la LÍNEA DE AIRE al acoplador.

2

Cierre la VÁLVULA DE DRENAJE en la parte inferior del tanque.





3

Llene la BOMBA DEL COMPRESOR hasta el nivel adecuado con ACEITE PARA COMPRESOR DE AIRE.
(el aceite se vende por separado)



4

Enchufe el cable a una toma de 120 Voltios a tierra y gire el INTERRUPTOR DE ALIMENTACIÓN a la posición de encendido (ON).

5

Si el COMPRESOR no arranca, presione el BOTÓN DE REINICIO.



CENTRALPNEUMATIC®

Configuración típica de la línea de aire



Se recomienda usar cinta para sellar roscas en todas las conexiones roscadas.

Accesorios recomendados

- Manguera de aire de $^{3}/_{8}$”
- Kit de accesorios de $^{1}/_{4}$”
- Filtro de aire en línea

No se recomienda el uso de un cable de extensión.